


# NCTU-EE IC Design LAB - Fall 2023

## Lab13 Power Rail Analysis Practice Tutorial

### 1. Flow overview





### 2. Set environment

- `unix% tar -xvf ~iclabta01/Lab13.tar`
- `unix% cd Lab12/Practice/05_APR`
- `unix% mkdir power_log` (You will save all the things here)
- `unix% innovus`
- Restore the design **DBS/CHIP.inn**

### 3. Static Power Analysis

1. Save CHIP.v
2. Write CHIP.sdf
3. Run post simulation at 06\_POST, the generated waveform CHIP\_POST.fsdbs will be used for power rail analysis.
4. In the innovus menu, open **Power -> Power Analysis -> Setup**



i. Click **OK**.

5. In the innovus menu, open **Power -> Power Analysis -> Run**


i. ◆Activity FILE ◆FSDB

ii. Fill the information:

- Select CHIP\_POST.fsdb (from 06\_POST)
- Scope: TESTBED/u\_CHIP
- Start: 0; Stop: 1000
- Press **Add**

iii. Results Directory: power\_log

iv. Click **OK**.




v. Results appear at terminal


```
Total Power
-----
Total Internal Power:      56.34742919      89.3507%
Total Switching Power:    6.69368832      10.6142%
Total Leakage Power:      0.02211333       0.0351%
Total Power:              63.06323143
```

## 4. Create Power Grid Library

1. In the innovus menu, open **Power -> Rail Analysis -> Set PG Library Mode**




- i. Cell type: **◆Tech Only**
- ii. Filler Cell Names: **FILL1 FILL16 FILL2 FILL32 FILL4 FILL64 FILL8**
- iii. Extraction
  - Extraction tech file: **05\_APR/RC/icecaps.tch** (File of type: All files(\*))
  - LEF Layermap: **05\_APR/layermap/lefdef.layermap.libgen**(File of type: All files(\*))
- iv. Supply Pins
  - Voltages: **1.8**
  - Power pin: **VCC**
  - Ground pin: **GND**
- v. Click **OK**



2. In the innovus menu, open **Power -> Rail Analysis -> Generate PG Library**

- i. Choose power\_log
- ii. Click OK



- iii. Check if the directory **techonly.cl** exists (under power\_log/)

3. In the innovus menu, open **Power -> Rail Analysis -> Set PG Library Mode**

- i. Cell type: ♦Std Cells
- ii. Filler Cell Names: **FILL1 FILL16 FILL2 FILL32 FILL4 FILL64 FILL8**
- iii. Extraction
  - Extraction tech file: **05\_APR/RC/icecaps.tch**
  - LEF Layermap: **05\_APR /layermap/ lefdef.layermap.libgen**
- iv. Supply Pins
  - Voltage: **1.8**
  - Power pin: **VCC**
  - Ground pin: **GND**
- v. Click **OK**.

The screenshot shows the 'Set PG Library Mode' dialog box with the following settings:

- Cell Type:** ☒ Std Cells
- Filler Cell Names:** FILL4 FILL64 FILL8
- Capacitance:** ☒ Area Cap(fF/um^2) 0.5
- Extraction:**
  - Extraction tech file: RC/icecaps.tch
  - LEF Layermap: ef.layermap.libgen
- Supply Pins:**
  - Power Pins: VCC
  - Voltages: 1.8
  - Ground Pins: GND

The 'OK' button is highlighted in red.


4. In the innovus menu, open **Power -> Rail Analysis -> Generate PG Library**

- i. Click
- ii. Check if the directory **stdcells.cl** exists (under power\_log/)

## 5. Rail Analysis

1. In the innovus menu, open **Power -> Rail Analysis -> Setup Rail Analysis**



- i. Analysis Method: **Static**
- ii. PowerGrid Libraries:  
power\_log/**technoly.cl** (should be added first)  
power\_log/**stdcells.cl**
- iii. Click



2. In the innovus menu, open **Power -> Rail Analysis -> Run Rail Analysis**

- i. ♦ Domain Based Domain Name: PD
- ii. Power Net(s): VCC Voltage(s): 1.8 Threshold:1.7 (Press **ADD**)  
Power Net(s): GND Voltage(s): 0 Threshold:0.1 (Press **ADD**)  
( $1.8v * 5\% \approx 0.1v$ )
- iii. Power/Current Files(s):  
**power\_log/static\_VCC.ptiavg**  
**power\_log/static\_GND.ptiavg**
- iv. Power Pads: ♦ XY File
- v. Click **Create**
  - Net Name: VCC
  - Click **Fetch**
  - Save as **power\_log/CHIP\_VCC.pp**
- vi. Click **Create** again
  - Net Name: GND
  - Click **Fetch**
  - Save as **power\_log/CHIP\_GND.pp**
- vii. Click **Cancel**
- viii. File: **power\_log/CHIP\_VCC.pp** Net Name: VCC (press **ADD**)
- ix. File: **power\_log/CHIP\_GND.pp** Net Name: GND (press **ADD**)
- x. Results Directory: **power\_log**
- xi. Click **OK**





## 6. Power & IR Drop Results

1. In the innovus menu, open **Power -> Report -> Power & Rail Result**

i. ♦Auto Apply for Color Scale

ii. Click **DB Setup**


● Power Databas: power\_log/power.db


● Rail Database: power\_log/**PD\_25C\_avg\_1**

● Click **OK**

iii. Type: ♦Rail

iv. Choose **ir – IR Drop**





# i. ◆Result Browser

The following shows the distribution of IR Drop (they should in the range **0.1V**)

